

Section 3 Cartridge receiving, processing:

3

General summary: This section supplies information on dismantling cartridges, converting hand-written log sheets to electronic files, and converting flow volumes and raw PM to mean 9-day air concentrations

Step 1: Receiving cartridge



Figure 1: Foreground: a disassembled SPARTAN cartridge




Figure 2: Cartridge assembly scheme. Left is TOP half (teflon), right is BOTTOM half (nuclepore). NB: we no longer use black o-rings. All o-rings are orange (softer than black, which makes a better seal)

Cartridges are received by way of courier (UPS, FedEx, DHL, or others). It has been our policy to ask sites to send us one cartridge at a time. Costs for shipping a single cartridge vary, but are approximately \$50 CAD. When shipping OUT cartridges or other supplies, always use UPS (very large discount applied to Dalhousie University)
We provide the following shipping address to all sites

[Name, e.g. Graydon Snider]
6310 Coburg Rd. room 218
Dalhousie University
Department of Physics and Atmospheric Science
Sir James Dunn bldg.
Halifax, NS
B3H 4R2
Phone: 902-494-1820

Inside along with cartridge itself should be a log sheet detailing when, for how long, and at what flow rate each filter sampled (a memory card sometimes included, depending on site, will have instrument-recorded data). By default each filter samples for 24 hours (actual sampling time), but many sites have a reduced duty cycle.

Valve Number	Filter Start Date (mm/dd/yyyy)	Filter End Date (mm/dd/yyyy)	Filter (Teflon)	Cartridge (Dallmeyer)	Internal Flow (lpm)	External Flow (lpm)	Internal Flow (lpm)	External Flow (lpm)
EXAMPLE	10/21/2013	11/01/2013	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
1	11/23/2013	12/01/2013	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
2	12/01/2013	12/10/2013	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
3	12/10/2013	12/18/2013	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
4	12/18/2013	12/28/2013	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
5	12/28/2013	01/06/2014	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
6	01/06/2014	01/15/2014	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
7	01/15/2014	01/24/2014	1100-0000-01	1100-0000-01	0.01	0.01	0.01	0.01
8			1100-0000-01	1100-0000-01	Blank	Blank	Blank	Blank

Short Period (days:hours:minutes:seconds):

Comments:
Tubes 1 & 2 were run normally but tube 3 to 7 were run automatically. Tube 1 & 2 were run from 9:30 am to 9:32 am everyday (11/23/2013 to 12/10/2013).

Figure 3: Sample log sheet from University of Dhaka, Bangladesh (BDDU). Note there is some information missing.

As with the above example (figure 2), some information is left incomplete. Please ask site operator more details, if any are missing such as post-sampling flow rates, omitted dates, or programmed times not logged.

Memory card data also logs flow information, however many sites have shown this data to be corrupt. In future editions corruption problem will be fixed. However external flows are still need as a spot check to for inconsistencies (e.g. leaks in flow system).

Step 2: Unloading cartridge

Once received (at main physics office), the cartridge(s) are taken to Sexton campus to Mark Gibson's AFRG laboratory, room N310. There you will find a drawer labeled "IN FIELD", which contains filter petri dishes labeled [Site Code]-[Cartridge #], e.g. INKA-004. Individual

filters are then labeled 13161-INKA-1T. Normally all 16 filters (8 Teflon, 8 Nuclepore) are grouped in one custom-made petri dish holder. Individual




Figure 4: petri dish holder () containing one Teflon filter from Tsinghua University, China (CHTS). This filter is 1 of 16 of the CHTS_011 cartridge filters (13161 to 13176).

Disassemble and unload the cartridge in the HEPA hood (with blower turned OFF!). First place a fresh large Kimwipe under HEPA space before disassembling (this provides a clean working surface).

Tools needed:

- Hex key (opening cartridge)
- Two pairs of clean tweezers
- Custom-made plug remover (see figure 1)
- Methanol (for wiping tweezers, cleaning parts)
- Milli-Q water (for cleaning parts)

Remove all 8 screws with hex key. Separate cartridge halves by flipping over the two 2x2 top halves containing the Teflon filters. Wipe tweezers and proceed to place filters in the appropriately labeled dishes. Grab only the edge of filters. Anticipate there may be static, especially for nuclepore. Teflon filters (opaque white) go in dishes labeled 1T, 2T,...8T. Nuclepore filters (translucent, very delicate) go in dishes labeled 1N, 2N,...8N. NB: The 8th slot is the blank and filter surface should look very clean.

Once all filters have been transferred to dishes, place filled petri dishes back into 16-slot filter holder. For added security, place two elastic bands lengthwise around the holder, and the ensemble into a medium-sized Glad or Ziploc plastic bag.

Step 3: Post-weighing filters

Packaged filters are brought to HERC (located in Dalhousie's LSRI building). Filters are unloaded from 16-slot holder and left to equilibrate for 24 hours. Please refer to **section 1** for explanation of pre and post-weighing procedures (identical to pre-weighing).

Once filters have been post weighed, they are measured for Equivalent Black Carbon (E-BC) via reflectance at HERC. Please refer to **section 6** for an explanation of E-BC measurements.

After BC measurements are performed at HERC, the filters are repackaged into same 16-slot filter holder and returned to Sexton (AFRG facility) for chemical analysis.

Please refer to **section 7 and 8** for ion chromatography (IC; cation & anion) and ICP nitric acid digestion.

Step 4: Transforming post-weigh and flow data into mass concentrations

In cartridge digital log Excel files compiled by Crystal Weagle you will find an outline like the following:

ARC8-001								
Duty minutes			131	scaling factor: 1 correction factor: 0				
PM2.5 Sampling Date Range	Filter ID	PM mass (ug)	PM Error	Average Flow (lpm)	Volume (mL)	PM2.5 conc. (ug/m ³)	PM2.5 corrected	Strep
10/02/2014 - 10/31/2014	13001-ARC8-17	35.83	3.4%	4.11	4.328	8.72	8.72	0.84
10/31/2014 - 10/20/2014	13002-ARC8-27	31.70	4.89	3.91	3.907	8.135	8.11	1.25
10/20/2014 - 10/29/2014	13003-ARC8-37	33.50	6.89	3.84	3.839	8.73	8.73	1.79
10/29/2014 - 11/07/2014	13004-ARC8-47	27.40	1.90	4.10	4.093	6.70	6.70	0.46
11/07/2014 - 11/16/2014	13005-ARC8-57	50.50	5.09	3.84	3.839	13.16	13.16	1.13
11/16/2014 - 11/25/2014	13006-ARC8-67	34.47	3.90	3.89	3.89	8.86	8.86	1.00
11/25/2014 - 12/04/2012	13007-ARC8-77	48.60	4.05	3.92	3.918	12.40	12.40	1.54
Blank	13008-ARC8-87	7.20	1.51	*	0.000			
				Average: 9.08		9.53		1.17
PM10 Sampling Date Range	Filter ID	PM mass (ug)	PM Error	Average Flow (lpm)	Volume (mL)	PM10 conc. (ug/m ³)		Strep
10/02/2014 - 10/31/2014	13009-ARC8-1N	27.07	2.55	4.11	4.328	6.59		0.62
10/31/2014 - 10/20/2014	13010-ARC8-2N	47.67	7.78	3.91	3.907	17.32		1.99
10/20/2014 - 10/29/2014	13011-ARC8-3N	56.70	7.92	3.84	3.839	14.77		2.06
10/29/2014 - 11/07/2014	13012-ARC8-4N	40.33	6.53	4.10	4.093	9.86		1.60
11/07/2014 - 11/16/2014	13013-ARC8-5N	65.87	3.41	3.84	3.839	17.16		0.89
11/16/2014 - 11/25/2014	13014-ARC8-6N	46.33	11.75	3.89	3.891	11.99		3.02
11/25/2014 - 12/04/2012	13015-ARC8-7N	86.93	1.91	3.92	3.918	22.19		0.49
Blank	13016-ARC8-8N	4.77	12.17	*	0.000			
				Average: 13.38				1.52

Figure 5: Raw mass data (micrograms) combined with flow rates (lpm) and sampling time (daily duty time x 9 days). Total flow volume (translated from litres to m³) is total sampling time x flow rate. PM2.5 and PMc concentrations are then Raw mass / Total flow Volume, reported as ug/m³. NB: we reject reported masses for nuclepore filters with > 160 ug deposited material and/or flow rates that have decreased by > 12% (approx. 3.5 lpm from an initial 4.0). Both instances indicate likely clogging of filter has occurred.

Digital log sheets should follow the above template for standardization and simplicity sake.

- The Filter ID is again the format 13nnn-XXXX-1T, etc. ,
- PM mass (ug) is the raw post-weighed mass from HERC weighing
- PM error is 1 standard deviation from two combined triplicate HERC weighing, e.g.

$$\Delta PM_{tot} = \sqrt{(\Delta PM_{pre})^2 + (\Delta PM_{post})^2}$$

- Average flow is usually the mean of the pre and post-measured external flow (exceptions include when internal flows are available).
- Volume is flow rate x time / 1000 (convert from l to m³)
- PM2.5 conc is PM mass / Volume

- PM_{2.5} corrected is based on SPARTAN-measured masses collocated with Harvard impactor filters. If data exists, we create a RMA plot of PM mass vs HI mass. This correction is subject to detailed analysis depending whether HI collocation has taken place, and whether values are properly correlated. By default scaling factor SF =1, correction factor CF =1. Equation is $PM_{corr} = SF \cdot PM_{meas} + CF$

It will take some time to figure out and collect site operator data, however once in the above format it will become much easier to digest.

PM_{2.5} mass concentration and time ranges shown in figure 6 is collected with other data from that site in a .csv file (see Sections 4-8).

```
location = BuenosAires_ARCB
tube      start_year start_month start_day start_hour stop_year stop_month stop_day stop_hour PM_2.5_abs Vol_m3 PM_2.5 scaling_factc correction_fr PM2.5_corr
13001-ARCB-1T 2014      10         2         9      2014      10        11         8 35.83333333 4.10779286 8.72325713 1 0 8.72325713
13002-ARCB-2T 2014      10        11         9      2014      10        20         8 31.7 3.90656439 8.11454692 1 0 8.11454692
13003-ARCB-3T 2014      10        20         9      2014      10        29         8 33.5 3.83850316 8.72736028 1 0 8.72736028
13004-ARCB-4T 2014      10        29         9      2014      11         7         8 27.4 4.09251834 6.6951441 1 0 6.6951441
13005-ARCB-5T 2014      11         7         9      2014      11        16         8 50.5 3.83858394 13.1558931 1 0 13.1558931
13006-ARCB-6T 2014      11        16         9      2014      11        25         8 34.46666667 3.89078319 8.85854209 1 0 8.85854209
13007-ARCB-7T 2014      11        25         9      2014      12         4         8 48.6 3.91845525 12.4028468 1 0 12.4028468
```

Figure 6: data entered in a Matlab-readable format

Other data will be added to columns right of PM_{2.5}_Corr. Note that nuclepore data is not collected and stored in this upload sheet. As of now we are not sharing the nuclepore chemical and physical analysis on the Sparta-network.org website.

Further columns in upload sheet require composition information collected from IC and ICP analysis (**steps 7 and 8**).